



ADC-WIND

User Manual

1.0 General Guide

Thank you for purchasing your new ADC. We recommend reading this manual, and practicing the operations before using your ADC in the field.

The ADC is designed to provide you with information essential to your needs. Data such as temperature, wind speed, barometric pressure, altitude and humidity are features specific to four different ADC models: Wind, Summit, Pro and JetSet.

Each ADC model is constructed to withstand water submersion and is ideal for conditions you endure during outdoor activities such as hiking, climbing, hunting, kayaking, skiing, and racing. Every ADC also includes current time, daily alarm, chronograph and race timer functions. ADCs are equipped with a propeller and other precise sensors to measure outdoor conditions.

WARNING !

- Make sure that you fully understand the functions and limitations of the ADC before relying on it.
- The ADC is an assisting device for the outdoor user, and is not a substitute for weather advisories from a weather station. It is helpful to check the readings provided by this product periodically with those broadcasted by the weather station.

2.0 Care and Maintenance

Prevent getting dirt in the ADC propeller. It could clog the mechanism.

Avoid exposing this product to extreme heat or extreme cold for an unreasonable amount of time.


Avoid severe impacts to the ADC.

Store the ADC in a dry place when it is not in use.


Clean the ADC with a soft moistened cloth occasionally.

DO NOT expose the ADC to strong chemicals such as gasoline and alcohol, as they will damage this product.

3.0 Part description



4.0 Button Operation Summary 1



Note:

The button operations are summarized in the following paragraphs, for detail operating instructions, please continue reading.

[mode] Button

Press the mode button to select among the major function modes

In function modes: Press and hold the mode button to select setting display

In any setting display: Press the mode button to select among different settings. Press and hold the mode button to exit setting sequence.

[set] Button

In Current Time Mode: press the set button to select the Daily Alarm Display.


In Daily Alarm Mode: Press the set button to switch the daily alarm between ON and OFF.

In Chronograph Mode and Race Timer Mode: Press the set button to start or stop the counting.

In Lap Time Recall Mode: Press the set button to select the available lap time(s).

In setting displays: press the set button to scroll through the settings.

4.1 Button Operation Summary 2



Note:

The button operations are summarized in the following paragraphs, for detail operating instructions, please continue reading.

[reset] Button

In Chronograph Mode (counting): Press the reset button to get Lap Time Display.

In Chronograph Mode (stop-counting): Press the reset button to reset the display to zero.

In Timer Mode (stop-counting): Press the reset button to reset the timer to target time.


In Lap Time Recall Mode: Press the reset button to select the available lap time(s).

In setting displays: press the reset button to scroll the through the settings.

[light] Button

In any functional mode/display, press the light button once to turn ON the EL backlight for about 3 seconds.


5.0 Major Functional Modes



6.0 Current Time Mode - Functional Displays

Day of week

Current
Time




Date
Year

Current
Temperature

Current Time Mode

7.0 Daily Alarm Mode - Daily Alarm Display



Daily Alarm Display

- In Daily Alarm Mode, the display will show the following:
 - 1) The mode indicator 'DAILY ALARM' appears on the 1st row of the display.
 - 2) The 'ON' or 'OFF' status indicator appears on the 2nd row of the display.
 - 3) The alarm time (hour and minute) appears on the 3rd row of the display.


To Select Daily Alarm between ON and OFF

- To select the daily alarm between ON and OFF, press the [set] button once.
- When the daily alarm is ON, the Alarm ON Indicator '🔔' appear otherwise it is OFF.

Daily Alarm Sound

- When the daily alarm is ON, the product will beep at the predefined alarm time for about 30 seconds.
- When the beep sounds, it can be stopped prematurely by pressing any of the buttons except the [light] button.

7.1 Daily Alarm Mode - Setting the Daily Alarm Mode





To Select the Setting Display

- Setting the Daily Alarm Time, press and hold the [mode] button for about 2 seconds to select the setting display (the 'minute' digits will start flashing).

The Setting Sequence

- In setting display, press the [mode] button to move the setting between minute and hour settings.
- When one of the settings (minute and hour) digits start to flash on the display, press the [set] or [reset] button to scroll through the setting (hold down the button to scroll the setting at a faster pace).
- When the setting finished, press and hold the [mode] button to exit the setting sequence.
- The setting display will change to Current Time Mode automatically if no key-stroke has been activated for about 1 minute.

8.0 Chronograph Mode - Chronograph Display



Elapsed Time, Accumulative Elapsed Time and Lap Time

..... : Stop Counting —————> : Counting


Chronograph Function

- The ADC is equipped with a Chronograph Mode, it can measure 3 different periods of time. They are:
 - Elapsed time,
 - Accumulative elapsed time
 - Lap time

Chronograph Display

- In Chronograph Mode, the display will show the following:
 - The mode indicator '*CHRONOGRAPH*' appears on the 1st and 2nd row of the display.
 - The chronograph time (hours, minutes, seconds) appears on the 3rd row of the display.
 - The lap number and chronograph time (1/100 second) appears on 4th row of the display.
- The display shows the 'Zero' display, if the product or the chronograph has been reset.
- The maximum counting range of the chronograph is 99 hours, 59 minutes and 59.99 seconds. The chronograph can record up to 50 laps.

8.1 Chronograph Mode - Using the Chronograph



Note:

This diagram illustrates the general flow among different functional displays only, and may NOT conform to fact in all instances.

Chronograph Function

- In 'Zero' Display, press the [set] button once to start the counting. When it is counting, press the [set] button again to stop the counting, and the elapsed time of which the chronograph is counting will appear.
- When the elapsed time is displaying, repeat the key operations above to get the accumulative elapsed time or press the [reset] button to reset the chronograph. Check the below 'To Reset the Chronograph' section for more detail on how to reset the chronograph.



To Record a Lap Time

- When the chronograph is counting in the previous operations, press the [reset] button to display Lap Time Display for 10 seconds.
- When the Lap Time is displaying, the chronograph remains counting in the background.

To Reset the Chronograph

- To reset the chronograph, to be ready for a new operation, press the [reset] button once when the chronograph has stopped counting. The display will then return to 'Zero' Display.

8.2 Chronograph Mode - Recall the Lap Time





To Recall the Lap Time

- In Stop Counting Display, press and hold the [mode] button to select the Chronograph Recall Display.
- In Chronograph Recall Display, the total elapsed time will appear. To recall the individual lap time, press the [set] or [reset] button to select the target lap time (hold down the button to scroll the setting faster) following the adjacent diagram.
- In Chronograph Recall Display, press and hold the [mode] button to return to the Stop Counting Display.

Chronograph Recall Display

- In Chronograph Recall Display, the display will show the following:
 - 1) The mode indicator 'CHRONO RECALL' appears on the 1st and 2nd row of the display.
 - 2) The lap time (hours, minutes, seconds) appears on the 3rd row of the display.
 - 3) The lap number and lap time (1/100 second) appears on the 4th row of the display.

9.0 Race Timer Mode - Race Timer Display




The Target Time

- The ADC is equipped with a countdown timer to keep track of a fixed period of time (target time).
- The user can set a target time of up to 99 hours, 59 minutes 59 seconds.
- Check the coming 'Setting the Race Timer Mode' section for more detail on how to set the target time in Racer Timer Mode.

Race Timer Display

- In Race Timer Mode, the display will show the following:
 - 1) The mode indicator 'RACE TIMER' appears on the 1st row of the display.
 - 2) The target time (hours, minutes, seconds) appears on the 3rd row of the display.
- The maximum counting range of the Race Timer is 99 hours, 59 minutes and 59 seconds.

9.1 Race Timer Mode - Setting the Race Timer Mode




To Select the Setting Display

- Setting the target time in Race Timer Mode, press and hold the [mode] button for about 2 seconds to select the setting display (the second digits will start flashing).

Setting Sequence

- In setting display, press the [mode] button to move setting following the adjacent diagram.
- When the one of the settings (second, minute, hour) start to flash, press the [set] or [reset] button to scroll through the settings (hold down the button to scroll at a faster pace).
- When the setting finished, press and hold the [mode] button for about 2 seconds to exit the setting sequence.
- The setting display will change to Race Timer Mode automatically if no key-stroke has been activated for about 1 minute.

9.2 Race Timer Mode - Using the Race Timer



Note:

This diagram illustrates the general flow among different functional displays only, and may NOT conform to fact in all instances.

To Use the Race Timer

- Once a target time has been set, press the [set] button once to start the countdown. When it is running, press the [set] button again to stop the countdown.
- The countdown time will be displayed continuously throughout the operation.



To Reset the Timer

- To reset the timer to the preset target time before the countdown reaches zero, press the [reset] button once when the timer has been stopped.
- To set a new value for the target time, check the previous 'Setting the Race Timer Mode' section for more detail on how to set the Racer Timer Mode.

Race Timer Alarm Sound

- At the last 10 minutes, the Alarm will beep once for every minute.
- At the last 10 seconds, the Alarm will beep once for every second.
- At zero, the Alarm will beep for about 2 seconds.

10.0 Wind Speed Mode - Before Using the Wind Speed Mode



Point the Propeller towards the wind direction

How Wind Speed is Measured

- The ADC is equipped with a propeller that is similar to a traditional anemometer.
- When the propeller faces the wind, it rotates and generates signal. This product will pick up the signal and converts it into wind speed.


Before and After Measuring a Wind Speed

- Turn the ball-shaped propeller by your thumb and index finger until the propeller blades are entirely exposed, and it is not sheltered by the case.
- After a wind speed measurement, rotate the propeller to a closed position to prevent dirt from getting into it.

To Measure Wind Speed

- Select Wind Speed Mode. Point the blades directly towards the wind direction, and make sure that the blades rotate freely.
- When the wind passes through the propeller, the blades rotate. The ADC starts to measure, and shows the current, average and maximum wind-speed readings.

10.1 Wind Speed Mode - Wind Speed Mode Function





Wind Speed Mode Functions

Wind Speed Mode Functions

- This ADC has the following wind speed functions:
 - 1) The Beaufort Scale: The longest and most widely used set of criteria to describe the wind conditions. Check the coming '*Beaufort Scale*' section for more detail on Beaufort Scale.
 - 2) The Current, Maximum and Average Average Wind Speed.
 - 3) Wind Speed Alarm: alarm that alerts the user when the current wind speed is higher than the predefined level.
 - 4) Wind Speed Display Lock: This feature can lock the wind speed display for 5 seconds.
 - 5) Time Span Setting: This feature defines the time for the Average Wind Speed Calculation. Check the coming '*Time Span Setting for Average Wind Speed*' section for more detail on the setting.

10.2 Wind Speed Mode - Wind Speed Display





Wind Speed Display

- In Wind Speed Mode, the display will show the following:
 - 1) The 'WIND' Indicator and the wind speed unit appear on the 1st row of the display.
 - 2) The Beaufort Scale (calculated by average wind speed) appears on the 2nd row of the display.
 - 3) The Current Wind Speed appears on the 3rd row of the display.
 - 4) The maximum and average wind speed appears on the 4th row of the display.


To Change Wind Speed Unit

- This ADC can display wind speed in the following wind speed units:
 - 1) Km/h (Kilometer per hour),
 - 2) mph (mile per hour),
 - 3) feet/s (feet per second)
 - 4) m/s (meter per second) and
 - 5) Knots.
- In Wind Speed Mode, press the [reset] button to change the wind speed unit following the adjacent diagram.

10.3 Wind Speed Mode - What is Beaufort Scale?



Example A: Number 5 of Beaufort Scale



Example B: Number 8 of Beaufort Scale

What is Beaufort Scale?

- Beaufort Scale is the longest and most widely used set of criteria to describe the wind conditions and its effects on land as well as on sea.
- It categorizes the wind speed into 13 force numbers, from 0 (calm) to 12 (hurricane). Check the 'Beaufort Scale Table' section below for more detail on the Beaufort Scale.

Beaufort Scale Bar


- For user's convenience, the ADC displays Beaufort Scale for average wind speed.
- The ADC exhibits Beaufort Scale by displaying different number of bars on the upper row of the display. One exhibited bar is equivalent to one Beaufort Scale force number. For example, if there are 5 bars on the display, the average wind speed is equivalent to force number 5 of Beaufort Scale.
- The ADC displays the Beaufort Scale force number from 0 to 10 (if the average wind speed is higher than force number 10, the ADC will display 10).

10.4 Wind Speed Mode - Beaufort Scale Table

Beaufort number	m/s	MPH	International Description	Observed conditions
0	< 1	<1	Calm	Calm; smoke rises vertically
1	1	1-3	Light air	Directions of wind shown by smoke drift but not by wind vanes
2	2	4-7	Light breeze	Wind felt on face; leaves rustle, vanes moved by wind
3	4	8-12	Gentle breeze	Leaves and small twigs in constant motion; wind extends light flag
4	7	13-18	Moderate	Raises duct, loose paper; small branches moved
5	10	19-24	Fresh	Small trees in leaf begin to sway; crested wavelets form on inland waters
6	12	25-31	Strong	Large branches in motion; whistling heard in telephone wires; umbrellas used with difficult
7	15	32-38	Near gale	Whole trees in motion; resistance felt walking against wind
8	18	39-46	Gale	Breaks twigs off trees; impedes walking
9	20	47-54	Strong gale	Slight structural damage occurs
10	26	55-63	Storm	Trees uprooted; considerable damage
11	30	64-72	Violent storm	Widespread damage
12	≥ 33	>73	Hurricane	

Beaufort Scale

10.5 Wind Speed Mode - Wind Speed Display Lock, Reset Max Wind Speed




Wind Speed Display Lock

- The ADC is equipped with a function to hold the fluctuating wind speed reading on the display.
- In Wind Speed Mode, press the [set] button to lock the wind speed reading (the display will hold the current reading for 5 seconds).

Reset the Maximum Wind Speed

- To reset the maximum wind speed, press and hold the [reset] button for 2 second to select the Reset Display.
- When the Reset Display is displayed, press the [set] button to select between 'YES' and 'NO'.
- In the 'YES' display, press and hold the [mode] button for 2 about seconds to confirm the reset (the maximum wind speed will reset to zero).
- To abort the reset, press and hold the [mode] button for 2 seconds in the 'NO' display.

10.6 Wind Speed Mode - Wind Speed Alarm




Wind Speed Alarm

- The ADC is equipped with a wind speed alarm.
- That alarm alerts user when the current wind speed is equal to or higher than the preset wind speed level.

Wind Speed Alarm Sound

- In Wind Speed Mode, if the Current Wind Speed is equal to or larger than the preset wind speed level, the ADC will start beeping for about 5 seconds.
- After the first beeping, the ADC will beep again for every 2 minutes if the current wind speed holds above the preset level.
- The above repeated alarm will stop unless the wind speed again exceeds the preset level or the wind speed alarm is set to OFF.


10.7 Wind Speed Mode - Setting the Wind Speed Alarm and Time Span



To Set the Wind Speed Alarm, and Time Span for Average Wind Speed Calculation

- To set the wind speed alarm, press and hold the [mode] button for about 2 seconds to select the setting display (wind speed starts flashing).
- When the 'wind speed' is flashing, press the [mode] button to select between time span setting and wind speed alarm setting.
- When 'wind speed' is flashing, press the [reset] button to scroll the target wind speed level by 1 step (hold down the button to scroll the setting faster). To select the wind speed alarm between ON and OFF, press the [set] button.
- When 'time' is flashing, press the [set] or [reset] button to scroll the target time span for average wind speed calculation by 1 (hold down the button to scroll the setting faster).
- Press and hold the [mode] button for about 2 seconds to exit the setting sequence.
- The setting display will change to Wind Mode automatically if no key-stroke has been activated for about 1 minute.

10.8 Wind Speed Mode - Using the Propeller as a Mechanical Compass



Using the Propeller as a Mechanical Compass


Propeller as a Mechanical Compass

- The ADC measures ambient temperature, wind speed, and it also tells compass directions.
- One of the propeller blades is red-colored to indicate the magnetic north pole.
- Four reference points were engraved on the ADC as reference points.

To use the Mechanical Compass

- To check bearing of an object, make sure that the propeller cover is opened, and the blades are entirely exposed to air.
- Tilt the ADC until the propeller blades are parallel to the horizon, and the propeller blades rotate freely.
- The red-colored blade of the propeller will point to the magnetic north pole. Make use of the reference points (marked on the product) to check the direction of the target object.

11.0 Temperature - Temperature Functions





Temperature Mode Functions

Temperature Mode Functions

- The ADC has the following temperature functions:
 - 1) The Current Temperature: The Current Temperature readings.
 - 2) The Current and Minimum Wind Chill temperature: The wind effect on temperature. Check the 'WindChill Temperature' section below for more detail on Wind Chill Temperature.
 - 3) The Temperature History Graph: The temperature memory for the last 24 hours.
 - 4) The Wind Chill Temperature Alarm: alarm to alert the user when the current Wind Chill Temperature is lower than the predefined limit.
 - 5) The Calibration: The process to calibrate the temperature reading.

11.1 Temperature - Temperature Display



Temperature Display

- In Temperature Mode, the display will show the following:
 - 1) The 'TEMP' Indicator and the temperature unit appear on the 1st row of the display.
 - 2) The Current Temperature appears on the 3rd row of the display.
 - 3) The Current and Minimum Wind Chill Temperature appear on the 4th row of the display.

To Change Temperature Unit

- The ADC can display temperature in the following units:
 - 1) Degree Celsius (C)
 - 2) Degree Fahrenheit (F)
- In Temperature Mode, press the [reset] button once to change the temperature unit. See adjacent figure.

11.2 Temperature Mode- Wind Chill Temperature

Case	Wind Conditions	Current Temperature	Wind Chill Temperature	Weather
1.	NO wind	15F/ -9.4C	15F/ -9.4C	Cold
2.	wind speed at 50 mph/ 80.5 km/h	15F/ -9.4C	-10F/ -23.3C	Very Cold
3.	NO wind	-10F/ -23.3C	-10F/ -23.3C	Very Cold

Wind Chill Temperature Effects


What is Wind Chill Temperature

- Wind chill is a temperature factor that combines air temperature and the effect of blowing wind.
- As blowing wind makes you feel as though the temperature is lower than simple air temperature.
- For example, if it is -9.4 degrees Celsius and the wind blows at 80.5 km per hour: People will feel as if the temperature is -23.3 degrees Celsius. In this case, the wind chill temperature is -23.3 degrees Celsius.
- The ADC is also equipped with wind chill temperature functions, including displaying current and minimum wind chill temperature, and having a wind chill temperature alarm.

Note:

- Wind chill temperature is the effect that combines wind speed and temperature, the ADC must measure the wind speed in order to display the wind chill temperature.
- Check the previous '*Before Using the Wind Speed Mode*' section for more detail on Wind Speed Measurement.

11.3 Temperature Mode - To Reset Minimum Wind Chill Temperature




Note:

This diagram illustrates the general flow among different functional displays only, and may not conform to fact in all instances.

To Reset the Minimum Wind Chill Temperature

- To reset the minimum wind chill temperature, press and hold the [reset] button for 2 seconds to select the Reset Display.
- When the Reset Display is displaying, press the [set] button to select between the 'YES' and 'NO' Display.
- In the 'YES' display, press and hold the [mode] button for about 2 seconds to confirm the reset (the minimum wind chill temperature will reset to zero).
- To abort the reset, press and hold the [mode] button for 2 seconds in the 'NO' display.


11.4 Temperature Mode - Temperature History Graph for the Last 24 Hours



Temperature History Graph

- The ADC is equipped with a temperature memory function. It records the last 24-hour temperature and displays them by bar-graph.
- In Temperature Mode, press the [set] button to select the Temperature History Graph Display.
- While in the Temperature History Graph Display setting, the right most bar will start flashing.
- The right most bar represents the current temperature (0 hour). While the other bars represent the temperature records of the last 24 hours. Each temperature record is taken at the hour (i.e. 12:00, 1:00, 2:00 ...)
- To browse the temperature record at different times, press the [set] button to select the record by backward scrolling or [reset] button to select time by forward scrolling (hold down the button to scroll the setting at a faster pace).
- Press the [mode] button once to exit the Pressure History Graph Display.

11.5 Temperature Mode - Wind Chill Temperature Alarm




Wind Chill Temperature Alarm

- The ADC is equipped with a wind chill temperature alarm.
- That alarm alerts user when the current wind chill temperature is equal to or lower than the preset wind chill temperature level.

Wind Chill Temperature Alarm Sound

- In Temperature Mode: When the Current Wind Chill Temperature is equal to or lower than the preset wind chill temperature level, the ADC starts beeping for about 5 seconds.
- After the first beeping, the ADC will beep again for every 2 minutes if the current wind chill temperature holds at or below the preset value.
- The above repeated alarm will stop unless the wind chill temperature equals or drops below the preset value or the wind chill temperature alarm is set to OFF.

11.6 Temperature Mode - Setting the Wind Chill Temperature Alarm




To Select Setting Display

- To select the setting display, press and hold the [mode] button for about 2 seconds to select the setting display (temperature digits will start flashing).

The Setting Sequence

- When the temperature digits are flashing, press the [mode] button to select between the Wind Chill Temperature Alarm Setting and Temperature Calibration Display following the adjacent diagram. Check the 'Calibrating the Temperature' section below for more detail on temperature calibration.
- When the temperature digits are flashing, press the [reset] button to scroll through to select target wind chill temperature level (hold down the button to scroll the setting at a faster pace), or press the [set] button to select the between wind chill temperature alarm ON and OFF.
- When the above settings finished, press and hold the [mode] button for about 2 seconds to exit the setting sequence.

11.7 Temperature Mode - Calibrating the Temperature



To Select Setting Display

- Following the previous 'Setting the Wind Chill Temperature Alarm' section to select the Calibration Display.
- In the Calibration Display, press and hold the [reset] button for 2 seconds to select the Calibration Setting Display.

The Setting Sequence

- When the 'offset value' digits are flashing, press the [set] or [reset] buttons scroll through to select target offset value (hold down the button to scroll the setting at a faster pace).
- When the above settings finished, press the [mode] button once to exit the setting sequence.

Note:

1) When the temperature has been calibrated, the ADC will offset the current temperature by the target offset value. For example: If the offset value is +2 and the current temperature is 26 degrees C, the ADC will display 28 degrees C (26+2).

2) The current wind chill temperature will be updated as above accordingly.

12.0 Specifications

Current Time Mode

- Hour, minute and second
- Month, day, day of week and year
- 12 / 24 hour format selectable
- Auto calendar from year 2003 to 2099

Wind Speed Mode

- Current, Average and Maximum Wind Speed
- Beaufort Scale for Average Wind Speed
- 5 Wind Speed Unit Selection (Km/h, mph, feet/s, m/s, and Knots).
- User defined time span for Average Wind Speed calculation.
- User defined Wind Speed Alarm.

Temperature Mode

- Current Temperature, and Current and Minimum Wind Chill Temperatures.
- User defined Wind Chill Temperature Alarm.
- Graphical and numerical displays for temperature for the last 24 hour

Daily Alarm Mode

- Daily Alarm: 1 daily alarm
- Alarm Duration: about 30 seconds

Chronograph Mode

- Resolution: 1/100 second
- Counting range: 99 hours, 59 minutes, 59.99 seconds
- Measurement: Elapsed time, accumulative elapsed time and lap time.
- Lap memory: 50 laps

Race Timer Mode

- Resolution: 1 second
- Setting limit: 99 hours, 59 minutes, 59 seconds
- Alarm sound:
 - Last 10 minutes: beep once for every minute.
 - Last 10 seconds: beep once for every second.
 - 0 second: beeps for about 2 seconds.

Others

- Electro-luminescent back-light turns on for 3 seconds when activated.

12.1 Accuracy, resolution and units

Wind Speed

Up to 3.0 m/s, better than +/-10%

Over 3.0 m/s, better than +/-5%

Resolution: 0.1 m/s

Units: m/s, km/h, mph, knots, ft/s

Temperature

Better than +/-1 Celsius degree (offset calibration possible)

Resolution: 0.1 degree

Units: Celsius, Fahrenheit

Time

Better than +/- 1 sec/day

13.0 Warranty

Brunton One Year Warranty

Brunton warrants this product to be free of defects in materials and workmanship for a period of one year. This warranty extends to the original purchaser from the date of purchase. This warranty is void and a charge for repair will be made if the ADC has been damaged by negligence, accident or mishandling, or has not been operated in accordance with standard operating procedures, or if the ADC was altered or repaired by anyone other than a Brunton repair facility. This warranty gives you specific legal rights, and you also have rights, which vary from state to state. No other warranty, expressed or implied, applies to the Brunton product, nor is any person or company authorized to assume any other warranty for Brunton. Brunton does not assume any responsibility for any consequential damages occasioned by this product. Should the product prove defective, contact Brunton, and you will be provided with a Return Authorization Number (RA#). Send a copy of your proof of purchase, the RA#, a short description of the problem and the product to Brunton at the following address. Brunton suggests insuring the product in case of damage or loss in shipment.

Brunton

Warranty Repair (307) 856-6559
620 East Monroe Avenue support@brunton.com
Riverton, WY 82501-4997 www.brunton.com

To register this product:

Print this form, fill out, and Send to Brunton at:

BRUNTON
WARRANTY
620 East Monroe Avenue
Riverton, WY 82501-4997

Name: _____
Address: _____
City: _____ State: _____ Zip: _____
Phone: _____ Email _____
Date Purchased: _____
Amount Paid: _____

Would you like to receive a Brunton Catalog? () Yes () No

Please let us know where you purchased your ADC

Store Name: _____
City: _____ State: _____ Zip: _____
() Online site _____ () Catalog _____
() Gift () Brunton
() Other _____

Do you own another Brunton Product?

() Yes. Product: _____ () No.

I purchased this Brunton ADC primarily for...

() Professional Use () It was a gift () It looked cool
() Recreational Use () Other _____

BRUNTON

ADC°WIND
